

HVO Summit S Series



Name

BUFFER Mode:

Distance - Ft.

OIL Mode:

Distances - Ft.

left outside :

left track :

left inside :

right inside :

right track :

right outside :

Transfer Rate %

Pass 1

Forward 38.0

Reverse 38.0

Forward 16.5

Reverse 0.0

Forward 22.0

Reverse 0.0

Forward 22.0

Reverse 25.0

Forward 34.0

Reverse 38.0

Forward 34.0

Reverse 0.0

Forward 16.5

Reverse 0.0

100

Pass 2

Forward 22.0

Reverse 25.0

Forward 1.0

Reverse 0.0

Forward 4.0

Reverse 0.0

Forward 7.0

Reverse 16.0

Forward 19.0

Reverse 25.0

Forward 7.0

Reverse 8.0

Forward 1.0

Reverse 0.0

100

SPEED SETTINGS:

Travel

Condition

Strip

Pass 1

Forward High

Reverse High

Forward High

Reverse High


Pass 2

Forward High

Reverse High

Forward Medium

Reverse Low



- Graph layers :
- Oil Pass 1 Forward
 - Oil Pass 1 Reverse
 - Oil Pass 2 Forward
 - Oil Pass 2 Reverse
 - Stripping

Handwritten signature